

To add contact number

Program Personal Telephone Number 1	[17] + [Personal Telephone Number 1] + [#]
Program Personal Telephone Number 2	[18] + [Personal Telephone Number 2] + [#]

Arm and Disarm when system call out to hand phone

To Force Arm Alarm : Hold down [4] for 2 seconds

To Disarm Alarm : [*], [PASSWORD], [#]

To Arm under Night Mode : Hold down [3] for 2 seconds

To Change User Password

[*], [MODE], [PASSWORD], [#], [01], [New Password], [Re-enter new Password], [#].

To Exit press : [MODE], [#]

Bypass Zone : Hold down [6] for 2 seconds, [Zone Number], [#].

View Alarm Memory : Hold down [8] for 2 seconds.

Panic Alarm : Hold down [P] for 2 seconds

Setting Telephone Number

[*], [MODE], [PASSWORD], [#], [17], [Tel No.], [#]
[18], [Tel No.], [#]

To Exit press : [MODE], [#]

System Call Out To Handphone

(Answer The Call) , (System will slow 2 short beeps) , (Press [Password] , [#])

Press [2] for : **Arm** (2 Short Beep) or
Disarm (1 Long Beep)

Press [1] for : System report ~ Zone 1 : 1 beep
Zone 2 : 2 beeps
"
"

Zone 8 : 8 beeps

Press [3] for : **On** or **Off** Siren

Press [5] for : **Bypass** or **Unbypass** Zone , [Zone Number] (1-9)

End Call press [#] wait until the phone automatic close .